



Install Guide for Acoustic Fire Hoods

To install small, medium or large cover.




Step One:

Grasp legs firmly and roll cover into a tight cylinder.
Ensure wiring loom is through slot before installation.



Step Two:

Keeping a tight grip on the legs, feed the cover through the cut out made for the down lighter.




Step Three:

Ensure cover has sprung back into its original cone shape.

(a) Grasp legs and pull down until L section clears the underside of the ceiling.

(b) Move legs out until vertical part of L section normal is flush with the side of the cut out.



Step Four:

Release legs so that they grip the underside of the tile.
Remove the excess of both legs. Cut at point A. Once cover is in place, down lighter can be fitted as normal.

EST. 1969

Crawley Mill, Dry Lane, Witney, Oxfordshire, OX29 9TJ
sales@soundservice.co.uk

VAT NO: GB 434 5018 73 REG NO: 960986



Tel: 0845 363 7131
Fax: 01993 779569

To install X-Large or XX-Large Cover.



Step One: Flatten the cover



Step Two: Fold the cover into quarters by folding it in half once



..... and then folding it in half again.



Step Three: Pass the folded cover through the aperture.



Step Four: Then fit the down lighter cover as per the manufacture's instructions - cables may be pushed through the vent slots in the cover. Check and ensure that there is a distance of 20mm minimum between the down lighter cover and any insulation or acoustic filling in the void.

Remote gearboxes and transformers must be situated outside of the down lighter cover.