


INSTALLING THERMAFLEECE IN WALLS

THERMAFLEECE is extremely versatile and can be used in many floor applications as an alternative to conventional insulation.

Solid Walls

THERMAFLEECE can be used as part of a system to internally insulate solid walls reducing energy loss in otherwise hard to heat properties.

THERMAFLEECE can be securely fitted between studwork to full-fill or part-fill the void.



Fit the insulation layers between studs ensuring all joints are close-butted to avoid air gaps. Overlap additional layers to reduce thermal bridging and air gaps. The friction of the insulation should hold it in place.


Fit a breather membrane to the inner face of the solid wall on the cold side of the insulation and fit a vapour control layer to the warm side before installing the wall finishing.

A service void can be created by counter battening along the timber frame and fixing an internal lining board. This ensures that the insulation remains undisturbed and airtightness remains intact when services are accessed for maintenance. The insulation performance of the void can be improved by replacing the VCL with an Eden Low Emissivity Membrane.

Standard electrical lighting cables can usually be placed within the insulation. Tack the cable to the side of the timber framework.

Standard Timber Frame Wall

A standard timber frame construction incorporates a 140mm timber stud with a 9mm racking board attached to the outer leaf to form a structural wall system. All internal load-bearing and non load-bearing walls are constructed using an 89mm timber stud.




Fix VCL to the warm side of the insulation to reduce the risk of interstitial condensation. The addition of vapour impermeable materials must be correctly detailed and materials must be completely sealed to ensure that no moisture can penetrate into the structure.

Thermafleece can be used to fill the wall void as part of a system to comply with Part L of the Building Regulations.

Twin Timber Frame Wall


Twin frame systems utilise two standard 89mm timber studs to allow a deeper timber frame that can be insulated to a greater thickness.



The twin frame system ensures that no thermal bridging occurs within the construction helping to maximise insulation performance. By using two 89mm structural timber frames, the width of the construction can be varied to achieve specific insulation performance.

Breathing Timber Frame Wall

Breathing wall timber frame systems incorporate a standard timber frame structure in conjunction with an external natural fibre insulation board. Thermafleece should be fitted between studs before the external components are installed. This provides a complete breathing wall structure without relying on breather membranes or internal vapour controls.




Unlike traditional timber frame systems, the racking board is positioned to the inside of the timber frame. The external insulation attached to the timber frame maintains the frame above the dewpoint temperature reducing the risk of condensation.

Additional benefits include low environmental impact, lightweight structure and improved insulation and airtightness.

“I” Beam Timber Frame Wall

The timber ‘I’ beam system is used to create a greater depth of timber frame which can be filled with a greater quantity of insulation. The structural timber frame ‘I’ beam section has a racking board attached to the cavity side of the construction. This gives the structure a high degree of strength. The system can also be fabricated as a closed panel system, delivered to site in sections that can be pre-insulated with the THERMAFLEECE.



A service void can be created by counter battening along the timber frame internal face and fixing the internal finishing board. This ensures that the insulation remains undisturbed and airtightness remains intact when services are accessed for maintenance. The insulation performance of the void can be improved by installing an Eden Low Emissivity Membrane against the insulation.

Technical Support

For further information and U-value calculations and compliance with current Building Regulations contact our Technical Helpline 0844 800995