


MDF6 - 6mm thick tongue and groove floor panels



Key Benefits

- Presents a stable surface for tiles and vinyl
- Easy to cut and install
- Only 6mm thick
- Can be used on top of Linoroll or QuietFloor
- Supplied in easy to handle panels
- Available from stock

Description

A 6mm thick MDF floor panel with tongue and groove joints. This easy to handle and use thin MDF panel has been specially developed for use on top of our Linoroll or QuietFloor impact absorbing acoustic underlay for vinyl, lino and ceramic tiles. It is both waterproof and fire resistant to Euro Class D of the new European classifications and can be glued or loose fitted on top of Linoroll or any other thin acoustic underlay of similar thickness.

For use on top of acoustic underlay

MDF6 flooring panels are designed for use on top of our Linoroll acoustic underlay for lino, vinyl and ceramic tiles or can be used on top of our QuietFloor if carpet tiles are to be fitted rather than normal carpet or engineered wood flooring.

Installation Instructions

1. Ensure the entire floor area is swept free of debris.
2. After gluing down the Linoroll wall to wall, glue the MDF panels on top as follows.
3. Work is commenced from one edge of the floor, staggering the joints in successive rows and working towards the exit. Ensure each panel is glued down using our Sta-Stuk contact adhesive.
4. Cut the groove from the long and short edges of the first corner board using a cross-cut saw..
5. Allow a 10mm expansion gap between the thin MDF panels and all walls or existing skirting. Seal this gap with Acoustic Sealant.
6. The last board in the first row is cut to length and the off-cut carried forward to commence the second row, ensuring that joints are staggered.
7. This procedure is continued until the last panel is fitted.
8. To ensure tight jointing, each tongue and groove is glued using a waterproof PVA adhesive.
9. Any unavoidable gaps are filled with Acoustic Sealant.
10. The completed floor must not be walked on for at least 48 hours to ensure the glue used in the construction has fully cured.

Once the joints are fully cured, the vinyl or lino can be fitted as normal. If ceramic tiles are to be used instead, these should be fixed using a flexible adhesive/grout.

If skirting boards are to be fitted after installation, ensure the bottom edge is at least 1mm clear of the floor to obtain maximum impact reducing performance.

Care must be taken not to damage the joints of the panels before installation. If any damage does occur, simply cut away the damaged section and use as normal or for cutting in.

ISOLGOMMA Linoroll-5 is made in Italy by Isolomma. These products are imported exclusively by Sound Service (Oxford) Ltd and are all made from recycled materials.

Isolomma are dedicated to the design and development of effective and eco friendly sound insulation materials.

Sound Service has been supplying these products in the UK for over 20 years.

ADDITIONAL INFORMATION AND INSTALLATION DETAIL CAN BE FOUND ON OUR WEBSITE

Sound Service (Oxford) Ltd, Crawley Mill, Witney, OX29 9TJ
www.soundservice.co.uk

Tel: 01993 704981 - Fax: 01993 779569